



E SEI IN MANI SICURE!

REFLEXX S.r.l.

INFORMATIVE NOTE

rev 00 del 23 giugno 2015

Product: Reflexx art. R101/ M - art. R101/ L - art. R101/XL - art. R101/ XXL

Emessa da G.Isetti - Amm.re Unico

Pag.: 1/3

NEOPRENE AND LATTICE GLOVES FLOCKLINED Black TRADEMARK REFLEXX 101HD

1. NAME AND ADDRESS OF MANUFACTURER:

REFLEXX S.R.L.

Via Passeri, 2

46019 VIADANA (MN)

Tel. 0375 833164 Fax. 0375 464504

2. GENERAL DESCRIPTION OF PRODUCT:

- ❑ Glove in natural latex mixed with polychloroprene, five fingers, black, light flockining internal, external clorinatura knurled non-slip surface.
- ❑ Multipurpose glove to protect the hand and/or the product handled; good chemical and mechanical resistance; it can be used for general purposes.
- ❑ glove used as Personal Protective Equipment (PPE) also against chemicals and microorganisms.
- ❑ Unit For Sale per pair in bag
- ❑ Outer packagings containing n° 50 bags (5x10)



Imballo - Pack

| 1 | | 50 | |
|----------------|---------------------|----------------|-------------------|
| Taglia Size | Articolo Article | Taglia Size | Cartone Carton |
| R101 M | 8032891632598 | M | 8032891637609 |
| R101 L | 8032891632604 | L | 8032891637593 |
| R101 XL | 8032891632611 | XL | 8032891637616 |
| R101 XXL | 8032891632628 | XXL | 8032891637623 |

REFLEXX S.r.l. Via Passeri, 2 46019 VIADANA (Mn) - Tel. + 39 0375833164 Fax + 39 0375464504

Capitale Sociale 300.000 euro (i.v.) Partita Iva 02085450209 R.E.A. 23166 - e-mail: info@reflexx.com www.reflexx.com



E SEI IN MANI SICURE!

| | | |
|--|-------------------------|----------------------------------|
| REFLEXX S.r.l. | INFORMATIVE NOTE | rev 00 del 23 giugno 2015 |
| Product: Reflexx art. R101/ M - art. R101/ L - art. R101/XL - art. R101/ XXL | | |
| <i>Emessa da G.Isetti - Amm.re Unico</i> | Pag.: 2/3 | |

3. QUALITY AND COMPLIANCE WITH REGULATIONS:

- As a PPE category III risk according to IT Legislative Decree 475/92 implementing Dir 89/686/EEC (SATRA _0321). The product is certified according to the EN 420 , EN 374 part I, II and III and EN 388.

4. DIMENSIONS AND PERFORMANCE:

| Dimensions (in mm.) | SIZE | | Length (min.) (± 10) | Thikness (± 0.03) |
|------------------------|------------------|---------|----------------------------|----------------------|
| | description size | size CE | | |
| | M | 8 | 320 | 0.68 |
| | L | 9 | 320 | |
| | XL | 10 | 320 | |
| | XXL | 11 | 320 | |

| | | |
|--------|------------------------|---------------|
| EN 420 | construction compliant | in compliance |
| | measures | in compliance |
| | donning | in compliance |

| | | |
|--------|----------------------|--------|
| EN 374 | test water loss | passed |
| | evidence of air leak | passed |

| | | |
|----------|------------------------------|---------------------------------|
| EN 374-3 | | Performance level of permeation |
| | Methanol | 2 |
| | Sodium hydroxide 40% | 6 |
| | Sodium hydroxide 25% | 6 |
| | Sodium Hypochlorite 25% | 6 |
| | Hydrochloric acid 25% | 6 |
| | Industrial alcohol denatured | 6 |
| | Sulfuric acid 96% | 4 |



E SEI IN MANI SICURE!

REFLEXX S.r.l.

INFORMATIVE NOTE

rev 00 del 23 giugno 2015

Product: Reflexx art. R101/ M - art. R101/ L - art. R101/XL - art. R101/ XXL

Emessa da G.Isetti - Amm.re Unico

Pag.: 3/3

| EN 388 | | Performance level |
|--------|---------------------------|-------------------|
| | Resistance to abrasion | 3 |
| | Resistance to blade cut | 1 |
| | Resistance to tear | 2 |
| | Resistance to perforation | 1 |

Gloves reflexx 101 are controlled according to the sampling method ISO 2859 < AQL 1.5 (level G1) for freedom from holes AQL 2.5 (level G1) for more defects and AQL 4.0 (level G1) for minor defects.

5. INSTRUCTIONS FOR USE AND STORAGE:

1. Please read carefully the information note before using the glove
2. Please keep this information note for the duration of the useful life of the glove
3. The product contains latex rubber. It may cause allergic reactions of type I hypersensitivity and delayed hypersensitivity type IV
4. Avoid contact with aggressive substances such as fats , oils , acids, hydrocarbons and other chemical agents ; has low resistance to ketone solvents
5. Before using the product, test it in real conditions of use
6. The glove is a device subject to wear and tear so it is recommended the frequent replacement , and in all cases where visually you can see imperfections. Always wear gloves your hands are dry and clean
7. Keep the packaging for further information and to ensure traceability
8. Keep the product in its original packaging in a dry place at a temperature not exceeding 40 °C or below -10 °C
9. Avoid exposure to sunlight and heat sources
10. The expiry date is indicated on the packaging and it is valid when the product must is properly stored

REFLEXX Srl
Via Passeri, 2 46019 VIADANA (MN)
P.I. e C.F. 02085450209
Tel. 0375.833164 - Fax 0375.464504
e-mail: info@reflexx.com