



E SEI IN MANI SICURE!

REFLEXX S.r.l.

INFORMATIVE NOTE

rev 03 del 08 settembre 2015

Product: reflexx 92 art. R92/ S - art. R92/ M - art. R92/ L - art. R92/ XL

Emessa da G.Isetti - Amm.re Unico

Pag.: 1/3

## LATEX GLOVES NOT FLOCKLINED TRADEMARK REFLEXX 92

### 1. NAME AND ADDRESS OF MANUFACTURER:

REFLEXX S.R.L.

Via Passeri, 2

46019 VIADANA (MN)

Tel. 0375 833164 Fax. 0375 464504

### 2 GENERAL DESCRIPTION OF THE PRODUCT

- Gloves Latex, five fingers, color natural / amber beaded drip and antiskid surface
- Gloves chlorinated internally for easy donning and also externally
- Gloves joined the pair (right hand and left hand) in a sealed envelope
- multipurpose glove to protect the hand and / or the product handled. It can be used for general purposes and may come into contact with different foods.
- Unit Sales per pair in envelope
- Outer packagings containing n ° 120 envelopes



#### Imballo - Pack

1		120	
Taglia Size	Articolo Article	Taglia Size	Cartone Carton
R92 S	8032891631560	S	8032891636565
R92 M	8032891631577	M	8032891636572
R92 L	8032891631584	L	8032891636589
R92 XL	8032891631591	XL	8032891636596

REFLEXX S.r.l. Via Passeri, 2 46019 VIADANA (Mn) - Tel. + 39 0375833164 Fax + 39 0375464504

Capitale Sociale 300.000 euro (i.v.) Partita Iva 02085450209 R.E.A. 23166 - e-mail: [info@reflexx.com](mailto:info@reflexx.com) [www.reflexx.com](http://www.reflexx.com)



E SEI IN MANI SICURE!

REFLEXX S.r.l.

INFORMATIVE NOTE

rev 03 del 08 settembre 2015

Product: reflexx 92 art. R92/ S - art. R92/ M - art. R92/ L - art. R92/ XL

Emessa da G.Isetti – Amm.re Unico

Pag.: 2/3

## 2. QUALITY AND COMPLIANCE WITH REGULATIONS:

- As a PPE category I risk according to IT Legislative Decree 475/92 implementing Dir 89/686/EEC. The product is certified according to the EN 420 and EN 374.

## 4. DIMENSIONS AND PERFORMANCE:

Dimensions (in mm.)	Size		Lenght (min.) (± 5)	Width in mm. (± 5)	Weight in g. (±3)	Thickness (± 0.4)
	Size description	CE size				
	S	7	300	90	45	0.30
	M	8	300	100	50	
	L	9	300	110	55	
	XL	10	300	115	60	

EN 420	measures	in compliance
	donning	in compliance
	dexterity	Maximum dexterity Class 5

## 5. INSTRUCTIONS FOR USE AND STORAGE:

1. Please read carefully the information note before using the glove.
2. Please keep this information note for the duration of the useful life of the glove.
3. Disposable Glove: PPE: Risk Category I (Directive 89/686 / EEC).
4. The product contains latex rubber. It may cause allergic reactions of type I hypersensitivity and delayed hypersensitivity type IV.
5. Avoid contact with aggressive substances such as fats , oils , acids, hydrocarbons and other chemical agents ; has low resistance to ketone solvents.
6. Before using the product, test it in real conditions of use



E SEI IN MANI SICURE!

**REFLEXX S.r.l.**

**INFORMATIVE NOTE**

**rev 03 del 08 settembre 2015**

Product: reflexx 92 art. R92/ S - art. R92/ M - art. R92/ L - art. R92/ XL

*Emessa da G.Isetti – Amm.re Unico*

Pag.: 3/3

7. The glove is a device subject to wear and tear so it is recommended the frequent replacement , and in all cases where visually you can see imperfections. Always wear gloves your hands are dry and clean.
8. Keep the packaging for further information and to ensure traceability
9. Keep the product in its original packaging in a dry place at a temperature not exceeding 40° C or below -10 °C.
10. Avoid exposure to sunlight and heat sources.
11. The expiry date is indicated on the packaging and it is valid when the product must be properly stored.

**REFLEXX Srl**

Via Passeri, 2 - 46019 VIADANA (MN)

P.I. e C.F. 02085450209

Tel. 0375.833164 - Fax 0375.464504

e-mail: [info@reflexx.com](mailto:info@reflexx.com)