



INFORMATIVE NOTE

Name: REFLEXX T22 Stretch	Date: 02/10/2024 Rev: 02															
MANUFACTURER REFLEXX SpA Via Passeri, 2 46019 VIADANA (MN) Tel.: + 39 0375 758891 Fax + 39 0375 464504 info@reflexx.com www.reflexx.com	<table><tr><th colspan="3">Pack</th></tr><tr><th>Cod./Size</th><th>Box</th><th>Carton</th></tr><tr><td>T22/S</td><td>8032891634882</td><td>8032891639887</td></tr><tr><td>T22/M</td><td>8032891634899</td><td>8032891639894</td></tr><tr><td>T22/L</td><td>8032891634905</td><td>8032891639900</td></tr></table>	Pack			Cod./Size	Box	Carton	T22/S	8032891634882	8032891639887	T22/M	8032891634899	8032891639894	T22/L	8032891634905	8032891639900
Pack																
Cod./Size	Box	Carton														
T22/S	8032891634882	8032891639887														
T22/M	8032891634899	8032891639894														
T22/L	8032891634905	8032891639900														

DESCRIPTION ■ Disposable glove, not sterile ■ **Material:** thermoplastic elastomer (TPE) ■ **Shape:** ambidextrous, five fingers ■ **Colour:** blue ■ **Feature:** internally powder-free; lightly embossed surface ■ **Packing:** 200 pieces/box; 10 boxes/carton

CONFORMITY AND PERFORMANCES



Personal Protective Equipment cat I for minimal risks only
 Reg EU 2016/425
 EN 420:2003 + A1 2009



Reg CE 1935/2004 – Reg UE 10/2011 - DM 21/03/73. To such use carefully read the declaration of suitability for food contact (DICA).

Cod./Size	Length min. (±8 mm)	Width (±3 mm)
T22/S (7)	260	95
T22/M (8)	270	110
T22/L (9)	280	120

Thickness min. mm	Palm (+/- 0.003)	0.05
----------------------	------------------	------

RECOMENDATIONS OF USE Multi-purpose glove to protect the hand and/or the handled product ■ Avoid contact with aggressive chemical elements and actions that could tear the glove ■ In case of transient skin reactions and hypersensitivity reactions, discontinue use and consult a doctor **WARNINGS** Before using the product, try it in the real condition of use ■ The glove is a device subject to wear, so frequent replacement is recommended and in all cases where imperfections are observed ■ Wear gloves with dry, clean hands ■ **STORAGE AND DISPOSAL** Store the gloves in their original packaging in a dry place. ■ Do not expose to direct sunlight and heat sources. ■ The expiry date is 3 years from the date of manufacture indicated on the sales package, and is valid for the product properly stored ■ Gloves must be disposed of according to local regulations ■ Product Declaration of Conformity on www.reflexx.com